

VOLVO INCAB1



Oil Pressure
Normal


Engine
Temp
Normal

Fuel good
for trip

Primary
Secondary
range
105-135psi

7°C
Empty
613 km 33 g
3 11:04 AM
839363.0 km

VOLVO INCAB2



Sterring Wheel
minimum play

De froster

Parking
Brake(Truck)

Dash lights &
headlight indicator

Parking
Brake
(Trailer)

Turn On Full All 3 to
check De froster


4 way
flashers



Highway
Horn

City Horn

VOLVO INCAB3



Side mirror
clean no
crack

Window
clean no
crack
roll up/down

Windsheild
clean no
crack

Wipers/
water
working

Side
mirror
clean
no
crack

Window
clean no
crack
roll
up/down

Seat Secure

Seat belt secure
no cut/twist